

To change the Time and Date in the model 7400E DWI:

1. Hold '**Zero**' key in for 10 seconds. Release when 'P XX' is displayed.
2. After the 'P' value is displayed, a 'C XX' number is displayed, then an 'AC XX' number is displayed – press '**Gross/Net**' four times to enter '0000' when 'AC XX' is displayed (default Access Code). Press '**Print**' to Enter.
3. Press the '**Gross/Net**' button repeatedly until 'SEL.OP3' is displayed.
4. Press the '**Zero**' key to display parameter 3.1
5. Press the '**Gross/Net**' key until either 12A (am) or 12P (pm) is displayed.
6. Press the '**Zero**' key to display parameter 3.2 tl.
7. Using the '**Gross/Net**' (shift digit) and the '**Tare**' (increment number) keys, enter the correct time (HHMMSS format), Press '**Print**' to enter.
8. Press '**Print**' to display 'SEL OP3'.
9. Press '**Print**' to display 'Ent AC'.
10. Press '**Print**' to exit to the weigh mode.

To change the Time and Date in the model 7600E DWI:

1. Hold '**Zero**' key in for 10 seconds. Release when 'P XX' is displayed.
2. After the 'P' value is displayed, a 'C XX' number is displayed, then an 'AC XX' number is displayed – type in '**0000 Enter**' when 'AC XX' is displayed. (default Access Code).
3. Press the '**Tare Recall**' button repeatedly until 'SEL.OP3' is displayed.
4. Press the '**Gross/Net**' key to display parameter 3.1
5. Press the '**Tare Recall**' key until either 12A (am) or 12P (pm) is displayed.
6. Press the '**Gross/Net**' key to display parameter 3.2 tl.
7. Using the **0-9 keypad**, enter the correct time (HHMMSS format), '**Enter**'.
8. Press '**Enter**' to display 'SEL OP3'.
9. Press '**Enter**' to display 'Ent AC'.
10. Press '**Enter**' to exit to the weigh mode.

Notes:

Certified Scales....

The Audit Trail (Software Certification Seal) is not changed if only the time and date is adjusted.

If any other parameters are changed, the Audit Trail is changed, requiring recertification.

The time and date needs to be adjusted when daylight saving time is beginning/ending.

If a mistake is made, press the "Print" key ('Enter' key for the 7600E) repeatedly to exit without saving.